Removing an MSATA SSD card on Snares

1. Turn laptop over and remove screws:

2. Push downward to remove cover

3. Remove screw holding MSATA SSD card in and remove MSATA SSD card